



**SHERWIN
WILLIAMS.**

PRICE QUOTATION

Account #: 2453-3676-3

03/30/2018
Quote #: 4130833

OAK RIDGE AT HIGH SPRINGS
NW 194TH ST
HIGH SPRINGS, FL 32643
(352) 373-2730

Project: PRICING LIST
Purchase Type: Annual Requirements

We are pleased to quote you as follows:

SALES NUMBER	SIZE	PRODUCT/REX NUMBER	DESCRIPTION	QTY	PRICE	EXT. PRICE
6403-89185	5 GAL	A82W00151	A-100® Exterior Latex Satin Extra White	5	\$29.17	\$145.85
Note: Standard Exterior						
6404-13779	5 GAL	A89W01151	SuperPaint® Exterior Latex Satin Extra White	5	\$33.17	\$165.85
Note: Upgraded Exterior						
6504-05830	5 GAL	K33W00251	Duration® Coating Exterior Latex Satin Extra White	5	\$48.47	\$242.35
Note: Premium Exterior						
6504-06788	5 GAL	D17W00151	Cashmere® Interior Acrylic Low Lustre Extra White	5	\$30.97	\$154.85
Note: Upgraded Interior						
6504-28204	GALLON	B09W01051	Harmony® IAQ Interior Acrylic Eg-Shel Extra White	5	\$38.77	\$193.85
Note: Upgraded Interior						
6500-96597	5 GAL	A97W01251	Duration Home® Interior Latex Satin Extra White	5	\$46.40	\$232.00
Note: Premium Interior						

We thank you for your consideration of Sherwin-Williams products and look forward to supplying these products to you.

Note: All prices are per gallon/unit.

TERMS OF THE SALE

Quotation Expires: 04/30/2018
F.O.B. Location:
Freight Terms:
Terms: As Agreed

By: Derrick Rosenberger

Store Address: 522 N E 23RD AVE
City: GAINESVILLE State: FL Zip: 32609 3637
Store Number: 2365
Phone: (352) 378-1384
Territory #: 6015

NOTICE: Please take notice that the quotation set forth above is not a contract and is subject to and conditioned upon approval by SHERWIN-WILLIAMS. In the event such approval is not obtained, you will be provided with a revised quotation and the quotation set forth above shall be null, void and of no force or effect. The pricing and recommendations detailed in this proposal represent confidential information provided by SHERWIN-WILLIAMS. We request that it not to be copied or shared with others outside your firm.

Data Pages



**SHERWIN
WILLIAMS.**

102.11

A-100[®]

Exterior Latex Satin

A82W00107 White

A82W00151 Extra White

A82W00153 Deep Base

A82T00154 Ultradeep Base

As of 11/07/2017, Complies with:			
OTC	Yes	LEED [®] 09 NC CI	N/A
OTC Phase II	Yes	LEED [®] 09 CS	N/A
SCAOMD	Yes	LEED [®] v4 Emissions	N/A
CARB	Yes	LEED [®] v4 VOC	Yes
CARB SCM2007	Yes		
Canada	Yes	MPI	Yes

CHARACTERISTICS

A-100 Exterior Latex is a quality exterior finish. This product is recommended for use on aluminum, vinyl, and wood siding, clapboard, shakes, shingles, plywood, masonry, and metal down to a surface and air temperature of 35°F.

Color: Most colors
To optimize hide and color development, always use the recommended P-Shadow primer

Coverage: 350 - 400 sq ft/gal
@ 4 mils wet; 1.4 mils dry

Drying Time, @ 50% RH:
@ 35-45°F @ 45°F +

Touch: 2 hour 2 hours

Recoat: 24-48 hours 4 hours

Drying and recoat times are temperature, humidity, and film thickness dependent

Finish: 10-20 units @ 60°

Tinting with CCE:

Base	oz/gal	Strength
Extra White	0-6	SherColor
Deep Base	4-12	SherColor
Ultradeep Base	10-12	SherColor

Extra White **A82W00151**
(may vary by base)

VOC (less exempt solvents):
<50 g/L; <0.42 lb/gal

As per 40 CFR 59.406 and SOR/2009-264, s.12

Volume Solids: 36 ± 2%

Weight Solids: 46 ± 2%

Weight per Gallon: 9.88 lb

Flash Point: N/A

Vehicle Type: 100% Acrylic

WVP Perms (US) 24.58
grains/(hr ft² in Hg)

Mildew Resistant

This coating contains agents which inhibit the growth of mildew on the surface of this coating film.

SPECIFICATIONS

Standard latex primers cannot be used below 50°F. See specific primer label for that product's application conditions.

Aluminum & Aluminum Siding¹

2 cts. A-100 Exterior Latex

Concrete Block, CMU, Split face Block

1 ct. Loxon Block Surfacers

2 cts. A-100 Exterior Latex

Brick

1 ct. Loxon Conditioner²

2 cts. A-100 Exterior Latex

Cement Composition Siding/Panels

1 ct. Loxon Concrete & Masonry Primer²

or Loxon Conditioner²

2 cts. A-100 Exterior Latex

Galvanized Steel¹

2 cts. A-100 Exterior Latex

Stucco, Cement, Concrete

1 ct. Loxon Concrete & Masonry Primer²

2 cts. A-100 Exterior Latex

Plywood

1 ct. Exterior Latex Wood Primer

2 cts. A-100 Exterior Latex

Vinyl Siding*

2 cts. A-100 Exterior Latex

Wood

1 ct. Exterior Oil-Based Wood Primer

2 cts. A-100 Exterior Latex

¹ On large expanses of metal siding, the air, surface, and material temperatures must be 50°F or higher.

² Not for use at temperatures under 50° F. See specific primer label for that product's application conditions.

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Seal stains from water, smoke, ink, pencil, grease, etc. with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Aluminum and Galvanized Steel

Wash to remove any oil, grease, or other surface contamination. All corrosion must be removed with sandpaper, wire brush, or other abrading method.

Caulking

Gaps between windows, doors, trim, and other through-wall openings can be filled with the appropriate caulk after priming the surface.

Cement Composition Siding/Panels

Remove all dirt, dust, grease, oil, loose particles, laitance, foreign material, and peeling or defective coatings. Allow the surface to dry thoroughly. If the surface is new, test it for pH, if the pH is higher than 9, prime with Loxon Concrete & Masonry Primer.



A-100[®]

Exterior Latex Satin

A82W00107 White
 A82W00151 Extra White
 A82W00153 Deep Base
 A82T00154 Ultradeep Base

<u>SURFACE PREPARATION</u>	<u>SURFACE PREPARATION</u>	<u>CAUTIONS</u>
<p>Masonry, Concrete, Block All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Acrylic Primer. Cracks, voids, and other holes should be repaired with an elastomeric patch or sealant.</p> <p>Steel Rust and mill scale must be removed using sandpaper, wire brush, or other abrading method. Bare steel must be primed the same day as cleaned.</p> <p>Stucco Remove any loose stucco, efflorescence, or laitance. Allow new stucco to cure at least 30 days before painting. If painting cannot wait 30 days, allow the surface to dry 7 days and prime with Loxon Concrete & Masonry Primer. Repair cracks, voids, and other holes with an elastomeric patch or sealant.</p> <p>*Vinyl or other PVC Building Products Clean the surface thoroughly by scrubbing with warm, soapy water. Rinse thoroughly, prime with appropriate white primer. Do not paint vinyl with any color darker than the original color. Do not paint vinyl with a color having a Light Reflective Value (LRV) of less than 56. Painting with darker colors lower than an LRV of 56 may cause vinyl to warp. Follow all painting guidelines of the vinyl manufacturer when painting. Only paint properly installed vinyl siding. Deviating from the manufacturer's painting guidelines may cause the warranty to be voided.</p> <p>Wood, Plywood, Composition Board Clean the surface thoroughly then sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. All new and patched areas must be primed. Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. If applied to these bare woods, it may show some staining. If staining persists, spot prime severe areas with 1 coat of Exterior Oil-Based Wood Primer prior to using.</p>	<p>Mildew Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised. Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p style="text-align: center;"><u>APPLICATION</u></p> <p>When the air temperature is at 35°F, substrates may be colder; prior to painting, check to be sure the air, surface, and material temperature are above 35°F and at least 5°F above the dew point. Avoid using if rain or snow is expected within 2-3 hours. Do not apply at air or surface temperatures below 35°F or when air or surface temperatures may drop below 35°F within 48 hours. No reduction necessary.</p> <p>Brush Use a nylon/polyester brush.</p> <p>Roller Use a 3/8" - 3/4" nap synthetic cover.</p> <p>Spray—Airless Pressure..... 2000 psi Tip..... .015"-.019"</p>	<p>For exterior use only. Protect from freezing. Non-photochemically reactive. Not for use on floors.</p> <p>Before using, carefully read CAUTIONS on label.</p> <p>HOTW 10/06/2017 A82W00151 37 36 KOR, Viet, SP, FRC</p> <p style="text-align: center;"><u>CLEANUP INFORMATION</u></p> <p>Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with a compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.</p>



**SHERWIN
WILLIAMS.**



SUPERPAINT®

Exterior Latex Satin

- A89W00116 Super White
- A89W01151 Extra White
- A89W00153 Deep Base
- A89T00154 Ultradeep Base
- A89Y00156 Light Yellow

As of 03/08/2018, Complies with:			
OTC	Yes	LEED® 09 NC CI	N/A
OTC Phase II	Yes	LEED® 09 CS	N/A
SCAQMD	Yes	LEED® v4 Emissions	N/A
CARB	Yes	LEED® v4 VOC	Yes
CARB SCM2007	Yes		
Canada	Yes	MPI	Yes

CHARACTERISTICS

SuperPaint Exterior Latex Satin, with improved resistance to early dirt pick up, provides outstanding performance on properly prepared aluminum and vinyl siding, wood, hardboard, masonry, cement, brick, block, stucco, and metal down to a surface and air temperature of 35°F.

VinylSafe™ paint colors allow you the freedom to choose from 100 color options, including a limited selection of darker colors formulated to resist warping or buckling when applied to a sound, stable vinyl substrate.

Color: Most colors
To optimize hide and color development, always use the recommended P-Shadow primer

Coverage: 350 - 400 sq ft/gal
@ 4 mils wet; 1.5 mils dry

Drying Time, @ 50% RH:
@ 35-45°F @ 45°F +
Touch: 2 hour 2 hours
Recoat: 24-48 hours 4 hours

Drying and recoat times are temperature, humidity, and film thickness dependent

Finish: 10-20 units @ 60°

Tinting with CCE:

Base	oz/gal	Strength
Extra White	0-6	SherColor
Deep Base	4-12	SherColor
Ultradeep Base	10-12	SherColor
Light Yellow	2-12	SherColor

Extra White A89W01151
(may vary by base)

VOC (less exempt solvents):
<50 g/L; <0.42 lb/gal
As per 40 CFR 59.406 and SOR/2009-264, s.12

Volume Solids: 38 ± 2%
Weight Solids: 49 ± 2%
Weight per Gallon: 10.19 lb
Flash Point: N/A
Vehicle Type: 100% Acrylic
WVP Perms (US) 26.14
grains/(hr ft² in Hg)

Mildew Resistant

This coating contains agents which inhibit the growth of mildew on the surface of this coating film.

SPECIFICATIONS

SuperPaint Exterior Latex Satin can be self-priming when used directly over existing coatings, or bare drywall, plaster and masonry (with a cured pH of less than 9). The first coat acts like a coat of primer and the second coat provides the final appearance and performance. Please note that some specific surfaces require specialized treatment.

Aluminum & Aluminum Siding¹, Galvanized Steel¹, Vinyl Siding

2 cts. SuperPaint Exterior Latex
Concrete Block, CMU, Split face Block
1 ct. Loxon Block Surfacer
2 cts. SuperPaint Exterior Latex
Brick

1 ct. Loxon Conditioner²
2 cts. SuperPaint Exterior Latex
Cement Composition Siding/Panels
1 ct. Loxon Concrete & Masonry Primer²
or Loxon Conditioner²
2 cts. SuperPaint Exterior Latex

Stucco, Cement, Concrete

1 ct. Loxon Concrete & Masonry Primer²
2 cts. SuperPaint Exterior Latex

Plywood

1 ct. Exterior Latex Wood Primer
2 cts. SuperPaint Exterior Latex
Wood (Cedar, Redwood)³
1 ct. Exterior Oil-Based Wood Primer²
2 cts. SuperPaint Exterior Latex

¹ On large expanses of metal siding, the air, surface, and material temperatures must be 50°F or higher.

² Not for use at temperatures under 50°F. See specific primer label for that product's application conditions.

³ Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. For best results on these woods, use a coat of Exterior Oil-Based Wood Primer.

Other primers may be appropriate. Standard latex primers cannot be used below 50°F. See specific primer label for that product's application conditions.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Seal stains from water, smoke, ink, pencil, grease, etc. with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Aluminum and Galvanized Steel

Wash to remove any oil, grease, or other surface contamination. All corrosion must be removed with sandpaper, wire brush, or other abrading method.

Caulking

Gaps between windows, doors, trim, and other through-wall openings can be filled with the appropriate caulk after priming the surface.

Cement Composition Siding/Panels

Remove all dirt, dust, grease, oil, loose particles, laitance, foreign material, and peeling or defective coatings. Allow the surface to dry thoroughly. If the surface is new, test it for pH, if the pH is higher than 9, prime with Loxon Concrete & Masonry Primer.



SUPERPAINT[®]

Exterior Latex Satin

- A89W00116 Super White
- A89W01151 Extra White
- A89W00153 Deep Base
- A89T00154 Ultradeep Base
- A89Y00156 Light Yellow

<u>SURFACE PREPARATION</u>	<u>SURFACE PREPARATION</u>	<u>CAUTIONS</u>
<p>Masonry, Concrete, Cement, Block All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer. Cracks, voids, and other holes should be repaired with an elastomeric patch or sealant.</p> <p>Steel Rust and mill scale must be removed using sandpaper, wire brush, or other abrading method. Bare steel must be primed the same day as cleaned.</p> <p>Stucco Remove any loose stucco, efflorescence, or laitance. Allow new stucco to cure at least 30 days before painting. If painting cannot wait 30 days, allow the surface to dry 7 days and prime with Loxon Concrete & Masonry Primer. Repair cracks, voids, and other holes with an elastomeric patch or sealant.</p> <p>*Vinyl or other PVC Building Products Clean the surface thoroughly by scrubbing with warm, soapy water. Rinse thoroughly, prime with appropriate white primer. Do not paint vinyl with any color darker than the original color or having a Light Reflective Value (LRV) of less than 56 unless VinylSafe[®] Colors are used. If VinylSafe colors are not used the vinyl may warp. Follow all painting guidelines of the vinyl manufacturer when painting. Only paint properly installed vinyl siding. Deviating from the manufacturer's painting guidelines may cause the warranty to be voided.</p> <p>Wood, Plywood, Composition Board Clean the surface thoroughly then sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. All new and patched areas must be primed. Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. If applied to these bare woods, it may show some staining. If staining persists, spot prime severe areas with 1 coat of Exterior Oil-Based Wood Primer prior to using.</p>	<p>Mildew Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised. Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p style="text-align: center;"><u>APPLICATION</u></p> <p>When the air temperature is at 35°F, substrates may be colder; prior to painting, check to be sure the air, surface, and material temperature are above 35°F and at least 5°F above the dew point. Avoid using if rain or snow is expected within 2-3 hours. Do not apply at air or surface temperatures below 35°F or when air or surface temperatures may drop below 35°F within 48 hours. No reduction necessary.</p> <p>Brush Use a nylon/polyester brush.</p> <p>Roller Use a 3/8" - 3/4" nap synthetic cover.</p> <p>Spray—Airless Pressure 2000 psi Tip015"-.019"</p>	<p><u>CAUTIONS</u></p> <p>For exterior use only. Protect from freezing. Non-photochemically reactive. Not for use on floors.</p> <p>Before using, carefully read CAUTIONS on label.</p> <p>HOTW 03/08/2018 A89W01151 36 39 Viet, KOR</p> <p style="text-align: center;"><u>CLEANUP INFORMATION</u></p> <p>Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with a compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.</p>



**SHERWIN
WILLIAMS.**

DURATION®
Exterior Acrylic Satin

K33W00200 Super White
K33W00251 Extra White
K33W00253 Deep Base
K33T00254 Ultradeep Base
K33Y00256 Light Yellow Base

As of 11/20/2017, Complies with:			
OTC	Yes	LEED® 09 NC CI	N/A
OTC Phase II	Yes	LEED® 09 CS	N/A
SCAQMD	Yes	LEED® v4 Emissions	N/A
CARB	Yes	LEED® v4 VOC	Yes
CARB SCM2007	Yes		
Canada	Yes	MPI	Yes

<u>DESCRIPTION</u>	<u>SPECIFICATIONS</u>	<u>SURFACE PREPARATION</u>															
<p>Duration® Exterior Latex Coating is the result of advances in acrylic technology. Duration uses PermaLast® technology to provide you with the most durable and longest lasting coating available for protecting the outside of your home.</p> <p>VinylSafe™ paint colors allow you the freedom to choose from 100 color options, including a limited selection of darker colors formulated to resist warping or buckling when applied to a sound, stable vinyl substrate.</p> <ul style="list-style-type: none"> • Self-priming One Coat Protection • Low temperature application down to 35° F. • Easy application • Excellent durability and hiding • Resists Blistering and Peeling <p>Color: Most colors Coverage: 250-300 sq ft/gal 5.3 - 6.4 mils wet; 2.1 - 2.6 mils dry up to 7.0 mils wet; 2.8 mils dft</p> <p>Drying Time, 50% RH: temperature and humidity dependent @ 35-45°F @ 45°F+</p> <p>Touch: 2 hour 1 hour Recoat: 24-48 hours 4 hours Finish: 10-20 units @ 60°</p> <p>Tinting with CCE only:</p> <table border="1"> <thead> <tr> <th>Base</th> <th>oz/gal</th> <th>Strength</th> </tr> </thead> <tbody> <tr> <td>Extra White</td> <td>0-7</td> <td>SherColor</td> </tr> <tr> <td>Deep Base</td> <td>4-14</td> <td>SherColor</td> </tr> <tr> <td>Ultradeep Base</td> <td>10-14</td> <td>SherColor</td> </tr> <tr> <td>Light Yellow</td> <td>4-14</td> <td>SherColor</td> </tr> </tbody> </table> <p style="text-align: center;">Extra White K33W00251 (may vary by base)</p> <p>VOC (less exempt solvents) <50 g/L; 0.42 lb/gal As per 40 CFR 59.406 and SOR/2009-264, s.12</p> <p>Volume Solids: 40 ± 2% Weight Solids: 50 ± 2% Weight per Gallon: 10.27 lb Flash Point: N/A Vehicle Type: Acrylic</p> <p>MILDEW RESISTANT. This coating contains agents that inhibit the growth of mildew on the surface of this coating.</p>	Base	oz/gal	Strength	Extra White	0-7	SherColor	Deep Base	4-14	SherColor	Ultradeep Base	10-14	SherColor	Light Yellow	4-14	SherColor	<p>Duration Exterior Acrylic Latex is self-priming on most surfaces. Apply 2 coats on new, bare substrates or 1 coat for repaint. Use on these properly prepared surfaces:</p> <p>Aluminum & Aluminum Siding¹ Galvanized Steel¹ Concrete Block Split face Block Cement Composition Siding/Panels Stucco Concrete Plywood Wood Vinyl Siding</p> <p>Surfaces with a pH greater than 9 must be primed with a high pH-resistant coating such as Loxon Concrete & Masonry Primer/Sealer.</p> <p>Standard latex primers cannot be used below 50°F. See specific primer label for that product's application limitations.</p> <p>Concrete masonry units (CMU) - Surface should be thoroughly clean and dry. Air, material and surface temperatures must be at least 50°F (10°C) before filling. Use Loxon Block Surfacer. The filler must be thoroughly dry before topcoating.</p> <p>Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. If applied to these bare woods, the first coat of DURATION may show some staining, but it will be trapped in the first coat. A second coat will uniform the appearance. If staining persists, spot prime severe areas with 1 coat of Exterior Oil-Based Wood Primer prior to using DURATION.</p> <p>¹ On large expanses of metal siding, the air, surface, and material temperatures must be 50°F or higher.</p>	<p>WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.</p> <p>Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Seal stains from water, smoke, ink, pencil, grease, etc. with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.</p> <p>Aluminum and Galvanized Steel Wash to remove any oil, grease, or other surface contamination. All corrosion must be removed with sandpaper, wire brush, or other abrading method.</p> <p>Caulking Gaps between windows, doors, trim, and other through-wall openings can be filled with the appropriate caulk after priming the surface. Allow proper drying time before application of the finish.</p> <p>Cement Composition Siding/Panels Remove all dirt, dust, grease, oil, loose particles, laitance, foreign material, and peeling or defective coatings. Allow the surface to dry thoroughly. If the surface is new, test it for pH, if the pH is higher than 9, prime with Loxon Concrete & Masonry Primer. After power washing, previously painted masonry may still have a powdery surface that should be sealed with Loxon Conditioner and then apply 1 coat of Duration.</p> <p>Composition Board/Hardboard Because of the potential for wax bleeding out of the substrate, apply 1 coat of Exterior Oil-Based Wood Primer and then topcoat.</p>
Base	oz/gal	Strength															
Extra White	0-7	SherColor															
Deep Base	4-14	SherColor															
Ultradeep Base	10-14	SherColor															
Light Yellow	4-14	SherColor															



102.14A

DURATION[®]

Exterior Acrylic Satin

K33W00200 Super White
 K33W00251 Extra White
 K33W00253 Deep Base
 K33T00254 Ultradeep Base
 K33Y00256 Light Yellow Base

<p><u>SURFACE PREPARATION</u></p> <p>Mildew-Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised. Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p>Previously Painted Surfaces-Spot prime bare areas with Duration, wait 4 hours, and paint the entire surface. Some specific surfaces require specialized treatment.</p> <p>Steel-Rust and mill scale must be removed using sandpaper, steel wool, or other abrading method. Bare steel must be primed the same day as cleaned.</p> <p>Stucco-Remove any loose stucco, efflorescence, or laitance. Allow new stucco to cure at least 30 days before painting. If painting cannot wait 30 days, allow the surface to dry 7 days and prime with Loxon Concrete & Masonry Primer. Repair cracks, voids, and other holes with an elastomeric patch or sealant.</p> <p>Unpainted Surfaces-Duration can be used as a self-priming coating on many bare surfaces. When used this way, the first coat of Duration acts like a coat of primer and the second coat provides the final appearance and performance.</p> <p>*Vinyl or other PVC Building Products Clean the surface thoroughly by scrubbing with warm, soapy water. Rinse thoroughly, prime with appropriate white primer. Do not paint vinyl with any color darker than the original color or having a Light Reflective Value (LRV) of less than 56 unless VinylSafe[®] Colors are used. If VinylSafe colors are not used the vinyl may warp. Follow all painting guidelines of the vinyl manufacturer when painting. Only paint properly installed vinyl siding. Deviating from the manufacturer's painting guidelines may cause the warranty to be voided.</p>	<p><u>SURFACE PREPARATION</u></p> <p>Wood- Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. All patched areas must be primed. Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. If applied to these bare woods, the first coat of DURATION may show some staining, but it will be trapped in the first coat. A second coat will uniform the appearance. If staining persists, spot prime severe areas with 1 coat of Exterior Oil-Based Wood Primer prior to using DURATION.</p> <p><u>APPLICATION</u></p> <p>Thoroughly follow the recommended surface preparations. Most coating failures are due to inadequate surface preparation or application. Thorough surface preparation will help provide long term protection with Duration coating. On repaint work, apply one coat of Duration coating; on bare surfaces, apply two coats of Duration, allowing 4 hours drying between coats.</p> <p>Do not paint in direct sun. Apply at temperatures above 35°F. During application at temperatures above 80°F, Duration sets up quickly. Some adjustment in your painting approach may be required. Paint from a dry area into the adjoining wet coating area. Dries to touch in 1 hour and is ready for service overnight.</p> <p>When the air temperature is at 35°F, substrates may be colder; prior to painting, check to be sure the air, surface, and material temperature are above 35°F and at least 5°F above the dew point. Avoid using if rain or snow is expected within 2-3 hours. Do not apply at air or surface temperatures below 35°F or when air or surface temperatures may drop below 35°F within 48 hours.</p> <p>On large expanses of metal siding, the air, surface, and material temperatures must be 50°F or higher.</p> <p>No reduction necessary.</p> <p>Brush - Use a nylon/polyester brush.</p> <p>Roller - Use a 3/8" - 3/4" nap synthetic cover.</p> <p>Spray—Airless Pressure 2000 psi Tip015"-.019"</p>	<p><u>CAUTIONS</u></p> <p>For exterior use only. Protect from freezing. Non-photochemically reactive.</p> <p>Before using, carefully read CAUTIONS on label.</p> <p>HOTW 11/20/2017 K33W00251 12 33 FRC,SP,KOR, VIET</p> <p><u>CLEANUP INFORMATION</u></p> <p>Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with a compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.</p>
--	--	--



**SHERWIN
WILLIAMS.**

101.14LL

CASHMERE®
Interior Acrylic
Low Lustre
D17-150 Series

As of 08/01/2013, complies with			
OTC	Yes	LEED® 09 CI	Yes
SCAQMD	Yes	LEED® 09 NC	Yes
CARB	Yes	LEED® 09 S	Yes
CARB SCM 2007	Yes	LEED® H	Yes
MPI #	-	NGBS	Yes

CHARACTERISTICS

Cashmere Interior Latex glides on but-tery smooth and levels out... giving walls an elegant, silky rich look. The result is a difference you can definitely see and feel.

- Ultra-smooth, rich, silky finish.
- Silky, low-stipple appearance that looks good from all angles.
- Looks, feels and applies smooth and buttery.
- Outstanding coverage and hide.
- Scrubbable for easy cleaning and maintenance.
- Ideal for residential spaces.

Color: Most colors
Drying and recoat times are temperature, humidity, and film thickness dependent

Coverage: 350 - 400 sq ft/gal
@ 4 mils wet; 1.4 mils dry

Drying Time, @ 77°F, 50% RH:
Touch: 1 hour
Recoat: 4 hours

Drying and recoat times are temperature, humidity, and film thickness dependent

Flash Point: N/A

Finish:
Gloss 5-15 units @ 60°
Sheen 35-45 units @ 85°

Tinting with CCE:

Base	oz/gal	Strength
Hi Refl White	0-5	100%
Extra White	0-6	125%
Deep Base	4-12	100%
Ultradeep Base	4-12	100%

Vehicle Type: Acrylic

D17W00151

VOC (less exempt solvents):
<50 g/L; 0.42 lb/gal
As per 40 CFR 59.406 and SOR/2009-264, s.12

Volume Solids: 39 ± 2%
Weight Solids: 51 ± 2%
Weight per Gallon: 10.7 lb

SPECIFICATIONS

Block

- 1 ct. Loxon Block Surfacer
- 2 cts. Cashmere Interior Latex

Drywall

- 1 ct. Premium Wall & Wood Primer
- 2 cts. Cashmere Interior Latex

Masonry

- 1 ct. Loxon Concrete & Masonry Primer/Sealer
- 2 cts. Cashmere Interior Latex

Plaster

- 1 ct. Premium Wall & Wood Primer
- 2 cts. Cashmere Interior Latex

Wood

- 1 ct. Premium Wall & Wood Primer
- 2 cts. Cashmere Interior Latex

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer/sealer.

Drywall

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete, Cement, Block

All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer/Sealer.



**SHERWIN
WILLIAMS.**

101.14LL

CASHMERE®
Interior Acrylic
Low Lustre
D17-150 Series

<u>SURFACE PREPARATION</u>	<u>APPLICATION</u>	<u>CAUTIONS</u>
<p>Plaster Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.</p> <p>Wood Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.</p> <p>Mildew Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p>Caulking Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.</p>	<p>Apply at temperatures above 50°F. No reduction needed.</p> <p>Brush Use a nylon/polyester brush <u>Preferred Brush:</u> Purdy- XL or Purdy- Clearcut Roller Use a 3/8" - 3/4" nap synthetic cover <u>Preferred Rollers:</u> Contractor Series Polyester or Purdy - Golden Eagle Spray—Airless Pressure..... 2000 psi Tip..... .017"-.021"</p> <p><u>CLEANUP INFORMATION</u> Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral spirits.</p>	<p>For interior use only. Non-photochemically reactive.</p> <p>LABEL CAUTION Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (NIOSH approved) or leave the area. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage. FIRST AID: In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.</p> <p>HOTW 07/24/2013 D17W00151 01 36</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative to obtain the most recent Product Data Sheet.</p>



**SHERWIN
WILLIAMS.**



101.76A

HARMONY[®] Interior Acrylic Eg-Shel

B09W01051 Extra White
B09W01053 Deep Base

As of 10/23/2017, Complies with:			
OTC	Yes	LEED® 09 NC, CI, CS	Yes
OTC Phase II	Yes	LEED® 09 H&S	Yes
SCAQMD	Yes	LEED® v4 Emissions	Yes
CARB	Yes	LEED® v4 VOC	Yes
CARB SCM 2007	Yes		
Canada	Yes	MPI	Yes

CHARACTERISTICS

- Formaldehyde Reducing Technology helps improve indoor air quality by reducing VOCs from possible sources like insulation, carpet, cabinets and fabrics.*
- Odor Eliminating Technology helps reduce common indoor odors so rooms stay fresher, longer.*
- Anti-microbial agents inhibit the growth of mold and mildew on the paint surface and inhibit the growth of bacterial odors.
- Zero VOC formula tinted with ColorCast Ecotoner[®] Colorants that do not add VOCs when tinted.
- Great hide and a durable finish that withstands frequent washings.
- Harmony's Formaldehyde Reducing Technology has been tested by a third-party laboratory.

Color: Most Colors
To optimize hide and color development, always use the recommended P-Shade primer

Coverage: 350-400 sq ft/gal
@ 4 mils wet; 1.7 mils dry

Drying Time, @ 77°F, 50% RH:

Touch: 1 hour
Recoat: 4 hours

Drying and recoat times are temperature, humidity, and film thickness dependent

Finish: 10 - 20 units @ 85°

Tinting with CCE only:

Base	oz/gal	Strength
Extra White	0-5	SherColor
Deep Base	4-12	SherColor

Extra White B09W01051
(may vary by base)

VOC (less exempt solvents):

<50 g/L; 0.42 lb/gal

As per 40 CFR 59.406 and SOR/2009-264, s.12

Volume Solids: 42 ± 2%

Weight Solids: 55 ± 2%

Weight per Gallon: 10.82 lb

Vehicle Type: 100% Acrylic

Flash Point: N/A

*The length of time Harmony actively reduces odors and formaldehyde depends on the concentration, the frequency of exposure and the amount of painted surface area.

SPECIFICATIONS

Block

- 1 ct. Loxon Block Surfer^{*}
- 2 cts. Harmony Interior Latex

Drywall

- 1 ct. Harmony Interior Latex Primer
- 2 cts. Harmony Interior Latex

Masonry

- 1 ct. Loxon Concrete & Masonry Primer/Sealer^{*}
- or Harmony Interior Latex Primer
- 2 cts. Harmony Interior Latex

Plaster

- 1 ct. Premium Wall & Wood Primer^{*}
- or Harmony Interior Latex Primer
- 2 cts. Harmony Interior Latex

Wood, Composition Board

- 1 ct. Premium Wall & Wood Primer^{*}
- or Harmony Interior Latex Primer
- 2 cts. Harmony Interior Latex

* These primers contain <50 g/L VOC.

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (**NIOSH** approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Drywall

Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete, Cement, Block

All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer.



101.76A

HARMONY[®]
 Interior Acrylic
 Eg-Shel

B09W01051 Extra White
 B09W01053 Deep Base

<u>SURFACE PREPARATION</u>	<u>APPLICATION</u>	<u>CAUTIONS</u>
<p>Plaster Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.</p> <p>Wood Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.</p> <p>Mildew Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised. Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p>Caulking Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.</p>	<p>Apply at temperatures above 50°F. No reduction necessary.</p> <p>Brush - Use a nylon/polyester brush.</p> <p>Roller - Use a 3/8" - 3/4" nap polyester or Soft Woven cover</p> <p>Spray—Airless Pressure 2000 psi Tip015"-.021"</p> <p><u>CLEANUP INFORMATION</u> Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.</p>	<p>For interior use only. Protect from freezing. Non-photochemically reactive.</p> <p>Before using, carefully read CAUTIONS on label</p> <p>HOTW 10/23/2017 B09W01051 16 00 FRC, SP</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.</p>



**SHERWIN
WILLIAMS®**

DURATION HOME®
Interior Latex
Satin
A97-1200 Series

As of 12/05/2017, Complies with:			
OTC	Yes	LEED® 09 NC CI	Yes
OTC Phase II	Yes	LEED® 09 CS	Yes
SCAQMD	Yes	LEED® 09 H	Yes
CARB	Yes	LEED® v4 Emissions	No
CARB SCM 2007	Yes	LEED® v4 VOC	Yes
Canada	Yes	MPI	Yes

CHARACTERISTICS

Duration Home Interior Latex Satin with Moisture Resistant Technology offering quick return to service & durability in moist environments like bathrooms. Also provides:

- Long lasting beauty
- Washability
- Resistant to stains, scuffs, & burnishing
- Very easy application
- Anti-Microbial*

Color: Most colors
To optimize hide and color development, always use the recommended P-Shadow primer

Coverage: 350 - 400 sq ft/gal
@ 4 mils wet; 1.6 mils dry

Drying Time, @ 77°F, 50% RH:
Touch: 1 hour
Recoat: 4 hours

Drying and recoat times are temperature, humidity, and film thickness dependent

Finish: 15 - 20 units @ 85°

Tinting with CCE:

Base	oz/gal	Strength
High Reflective	0-6	SherColor
Extra White	0-7	SherColor
Deep Base	4-12	SherColor
Ultra Deep	10-12	SherColor
Accent	12-20	SherColor
Real Red	0-12	SherColor
Bright Yellow	0-12	SherColor

Extra White A97W01251
(may vary by color)

VOC (less exempt solvents): <50 g/L; 0.42 lb/gal
As per 40 CFR 59.406 and SOR/2009-264, s.12

Volume Solids: 39 ± 2%

Weight Solids: 50 ± 2%

Weight per Gallon: 10.50 lb

Flash Point: N/A

Vehicle Type: Styrene Acrylic

***Anti-microbial**

This product contains agents which inhibit the growth of mold and mildew on the surface of this paint film.

SPECIFICATIONS

Duration Home Interior Latex can be used directly over existing coatings, bare drywall, or plaster (cured with a pH of less than 9).

Block

1ct. Loxon Block Surfacers
2cts. Duration Home Interior Latex

Drywall

Self-prime using 2 cts. of Duration Home Interior Latex

or
1ct. Premium Wall & Wood Primer
2cts. Duration Home Interior Latex

Masonry

1ct. Loxon Concrete & Masonry Primer
2cts. Duration Home Interior Latex

Plaster

Self-prime using 2 cts. of Duration Home Interior Latex

or

1ct. Premium Wall & Wood Primer
2cts. Duration Home Interior Latex

Wood, Composition Board

1ct. Premium Wall & Wood Primer
2cts. Duration Home Interior Latex

Other primers may be appropriate.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Drywall

Fill cracks and holes with patching paste or spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.

Masonry, Concrete, Cement, Block

All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer.



DURATION HOME[®]

Interior Latex Satin A97-1200 Series

<u>SURFACE PREPARATION</u>	<u>APPLICATION</u>	<u>CAUTIONS</u>
<p>Plaster Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.</p> <p>Wood Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.</p> <p>Mildew Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.</p> <p>Remove mildew before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p>Caulking Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.</p>	<p>Apply at temperatures above 50°F. No reduction needed.</p> <p>Brush Use a nylon/polyester brush.</p> <p>Roller For best final appearance when rolling, finish off in one direction, especially for dark colors. Use a high quality nylon/polyester roller cover.</p> <p>Spray—Airless Pressure2000 psi Tip..... .015"-.019" For touching-up, reduce the product by one pint per gallon.</p> <p style="text-align: center;"><u>TIPS</u></p> <p>To assure maximum washability and durability, wait at least 14 days before washing Duration Home Coating.</p> <p>When removing stains, dirt, and marks, use a soft cloth or sponge with water. Stubborn stains may require the use of a general purpose household cleaner for total removal. Do not use an abrasive cleaner or scrub brush to remove stains.</p> <p>Surfactant leaching is a term used when a concentration of water-soluble paint ingredients called "surfactants" are noticed on the surface of a latex paint film. Surfactant leaching is most commonly seen as a streak or stain of tan, brown, or clear spots that sometimes can be glossy, soapy, oily or even sticky. Surfactants are soap-like materials that help in the dispersion of the paint's pigment and latex binders. Duration Home with Moisture Resistant Technology has excellent resistance to surfactant leaching when applied on new or existing substrates. However, surfactants can remain on existing painted surfaces if not removed prior to coating. Existing painted surfaces must be thoroughly washed clean and allowed to dry prior to applying any finish.</p>	<p>For interior use only. Protect from freezing. Non-photochemically reactive.</p> <p>Before using, carefully read CAUTIONS on label.</p> <p>HOTW 12/05/2017 A97W01251 23 32 Viet, FRC,KOR, SP</p> <p style="text-align: center;"><u>CLEANUP INFORMATION</u></p> <p>Clean spills and spatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. Flush spray equipment after cleaning with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.</p>